


Rs-Pi – i2c 23017-2-BP User Manual



1. J23 GA0 ~ GA7,GND,INTA U13 Port A
2. J24 GB0 ~ GB7,GND,INTB U13 Port B
3. J25 GA0 ~ GA7,GND,INTA U14 Port A
4. J26 GB0 ~ GB7,GND,INTB U14 Port B
5. R61,R62,R63 (for U13 Address select A0,A1,A2)
6. R64,R65,R66 (for U14 Address select A0,A1,A2)
7. U13 (21) 23017 -1 Port A,B U14 (22) 23017-2 Port A,B


1. Make sure you I2C driver are enable

To enable it all you need to do is comment out a line by putting # in front

`sudo nano /etc/modprobe.d/raspi-blacklist.conf`



2. Add i2c-dev in /etc/modules by use `sudo nano /etc/modules`



```

192.168.0.13 - PuTTY
GNU nano 2.2.6 File: /etc/modules Modified
## /etc/modules: kernel modules to load at boot time.
#
# This file contains the names of kernel modules that should be loaded
# at boot time, one per line. Lines beginning with "#" are ignored.
# Parameters can be specified after the module name.

snd-bcm2835
spi-bcm2708
i2c-bcm2708
i2c-dev
rtc-ds1307

```

If you already install I2c driver , then

```
i2cdetect -y 0      i2cdetect -y 1
```

if Rs-Pi-v2 you need change 0 to 1

```

192.168.0.13 - PuTTY
Linux raspberrypi 3.6.11+ #456 PREEMPT Mon May 20 17:42:15 BST 2013 armv6l

The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.

Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
Last login: Thu Jan  1 00:00:50 1970
root@raspberrypi:~# i2cdetect -y 1
   0  1  2  3  4  5  6  7  8  9  a  b  c  d  e  f
00:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
10:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
20: 20 21 --  --  --  --  --  --  --  --  --  --  --  --  --
30:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
40:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
50:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
60:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
70:  --  --  --  --  --  --  --  --  --  --  --  --  --  --  --
root@raspberrypi:~#

```

You should see something like 20 & 21 -> 23017 x2

Next install the python-smbus python module:

```
sudo apt-get install python-smbus
```

```
sudo apt-get install i2c-tools
```

Now you are ready to use the i2c with python.

Some 23017 program information

<http://nathan.chantrell.net/20120524/python-tools-for-the-mcp23017-io-expander/>

<http://nathan.chantrell.net/20120602/raspberry-pi-io-expander-board>

<http://learn.adafruit.com/mcp230xx-gpio-expander-on-the-raspberry-pi/hooksing-it-all-up>

```

COM12 - PuTTY
root@raspberrypi:/home/pi/mcp230xx# dir
23008.py  23017-22.py  mcp23008.py  mcp23017.wsgi
23017-21.py  lcd1602.py  mcp23017.py  README
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py
Usage: 23017-21.py -b <bank> -o <output> -s <high|low>
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py -b a -o 0 -s high
Output GPA0 changed to high
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py -b a -o 1 -s high
Output GPA1 changed to high
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py -b a -o 5 -s high
Output GPA5 changed to high
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py -b a -o 7 -s high
Output GPA7 changed to high
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py -b a -o 5 -s low
Output GPA5 changed to low
root@raspberrypi:/home/pi/mcp230xx# ./23017-21.py -b a -o 4 -s high
Output GPA4 changed to high
root@raspberrypi:/home/pi/mcp230xx#

```

use 23017-21.py set each bit to be High or Low

or use led-21.py and led-22.py led chaser program, can download from our web site

```

COM22 - PuTTY
Output test for MCP23017
 8  7  6  5  4  3  2  1
A1 [0] [0] [0] [0] [0] [0] [1]
A2 [1] [0] [0] [1] [0] [0] [1] [0]
B1 [0] [0] [0] [0] [0] [0] [0] [1]
B2 [0] [0] [0] [0] [0] [0] [1] [0]

Enter the Bank ( A-B ), Port ( 1-2 ) and LED number ( 1-8 )
Type RES to Reset.
Example "A21" or "a21" will Toggle Bank A, Port 2, LED 1.
>


```

23017-2port-s-v103.py demo display all 32 GPIO status and set each bit to be High or Low


A0, A1, A2 address

* right side GND low - 0 * left side Vcc High - 1


000 - 20




001 - 21




010 - 22




011 - 23




100 - 24




101 - 25



110 - 26



111 - 27



Download test program on our web site Python & C

Python

<http://www.pridopia.co.uk/pi-23017-2-bp.html>

C code

<http://www.pridopia.co.uk/pi-i2c-23017x2-2803x2.html>

<https://pypi.python.org/pypi/RPi.GPIO> GPIO library

GPIO library - RPi.GPIO-0.5.6.tar.gz

Install python , library and run the test program

```
# sudo apt-get install python-dev
```

```
# wget http://www.pridopia.co.uk/pi-pgm/RPi.GPIO-0.5.6.tar.gz
```

```
# gunzip RPi.GPIO-0.5.6.tar.gz
```

```
# tar -xvf RPi.GPIO-0.5.6.tar
```

```
# cd RPi.GPIO-0.5.6
```

```
# sudo python setup.py install
```

```
# sudo python xxx.py ( xxx is your python program name)
```

New Pridopia scratch interface software you can download from our web site

<http://www.pridopia.co.uk/rs-pi-set-scratch.html>

Command "i2"+ "address(20-27)" + "a" +"bit(1 to 8)" for Port A

Command "i2"+ "address(20-27)" + "b" +"bit(1 to 8)" for Port B

Command "bit"+ "address(20-27)" + "a" +"bit(8 to 1)" for Port A

Command "bit"+ "address(20-27)" + "b" +"bit(8 to 1)" for Port B

i221a1 --> i2c address 21 Port A bit 1 ON/OFF

i222b4 --> i2c address 22 Port B bit 4 ON/OFF

bit22b01010101 --> address 22 port B from bit 8 to 1
output --> 01010101

bit21a01010101 --> address 21 port A from bit 8 to 1
output --> 01010101

bit21aoff --> address 21 Port A all OFF/clear

bit21boff --> address 21 Port B all OFF/clear

bit22aoff --> address 22 Port A all OFF/clear



U1 to U2 i2c 23017 address 21,22